

Glossary

in.	Inches.
INL	Integral Nonlinearity—A measure in LSB of the worst-case deviation from the ideal A/D or D/A transfer characteristic of the analog I/O circuitry.
interrupt	A computer signal indicating that the CPU should suspend its current task to service a designated activity.
interrupt level	The relative priority at which a device can interrupt.
I _{OH}	Current, output high.
I _{OL}	Current, output low.
K	
KB	Kilobytes—1,024 bytes when referring to memory.
L	
LED	Light-emitting diode.
LSB	Least significant bit.
M	
m	Meters.
max	Maximum.
min	Minimum.
MSB	Most significant bit.