



3. Hang the mounting bracket from the slot on the power rail.



4. Pivot module downward and align the guide pins on the power rail with the guide pin holes in the back of the module.



TIP

The IAM module can have two or three power rail connectors and guide pins. The AM module can have one or two, all other modules have one.